

Menu Structure Smart Soundbar 10

Speaker-Setup (SPS)

Channel Level (CHL)	Testtone Front L+R Center Surround L+R Top Front L+R Sub (TON FL FR CE SR SL TFL TFR SUB)
Distance (DST)	Front L+R Center Surround L+R Subwoofer (FL FR CE SR SL SUB)
Equalizer (EQ)	Soundbar Front L+R Surround L+R Top Front L+R SUB (SBR FL FR SR SL TOP FL FR SUB)
Voice Clarity (VOI)	Off On (OFF ON)
Room Height (RHE)	100 cm - 500 cm
Device Height (DHE)	1 cm - 100 cm

System-Setup (SYS)

Sleep Timer (SLP)	Off 15 30 45 60 (OFF 15 30 45 60)
IR Menu (IRM)	IR Learn Discrete Input Learn IR Clear (IRL DIL CLR)
HDMI CEC (CEC)	Off On (OFF ON)
Standby Mode (STB)	Eco Network Stand by Signal Detection, Manuel (ECO NSB AUT MAN)
Input Configuration (INP)	Input Name(HD1,HD2,HD3 ARC Opt Coax AUX) , Analog Gain (-6 - +6) (NAM (HD1,HD2,HD3 ARC COAX AUX), OFS (-6 - +6))
Input Selection (SEL)	Manuel Automatic (MAN AUT)
SUB Out (SUB)	Off Wired Wireless (OFF WRD WLS)
Phase SUB (PHA)	0 - 180
Lip sync (LIP)	0 - 200
Max. Volume (VOL)	0 - 70
DRC (DRC)	Off On (OFF ON)
Language (LAN)	German English (GER EN)
Factory Reset (RES)	Yes No (YES NO)

Network-Setup (NWS)	Network Select (NWC)	Wireless Wired (WLS WRD)
	Network Reset (NWR)	Yes No (YES NO)

Wireless-Setup (WIS)	Wireless Pairing (WSP)	Front L +R Surround L +R Top L+R Subwoofer (FL FR SI SR TFL TFR SUB)
	RF Power (TXP)	ECO Medium Maximum (ECO MED MAX)
	RF Channel (NWR)	Automatic; 5,2 GHz 1-3; 5,8 GHz 1-3 (AUT 5 2 1-3 5 8 1-3)
	Bluetooth Setup (BT)	Pair mode BT Select Bluetooth Reset Autoplay (BTP BTS BRE ATP)

System Info (INF)	Firmware Info (FWI)	WiFi Google Cast MCU Host STS Wireless DSP Audio OSD Fonts (WIF GC MCU STS DSP OSD)
	Network Info (WWI)	IP Adress MAC Adress Name SSID WiFi Band STS Wireless (IPA MAC NAM SSI BAN STS)

